





- | | |
|------------------------------------|---------------------------------------|
| PL Instrukcja montażu | UA Інструкція по установці |
| GB Assembly instruction | H Szerelési útmutató |
| D Montageanleitung | RO Instrucțiuni de montaj |
| SK Návod na inštaláciu | FR Instruction de montage |
| CZ Pokyny k instalaci | IT Istruzioni di montaggio |
| RUS Инструкция по установке | ES Instrucciones de ensamblaje |
| AE تعليمات التجميع | |
-



ALIENTA A/E




[09] x6




[10] x4 (ST3.5x8)




[11] x6 (ST4x35)



[12] x4




[13] x4







[14] x4




[15] x1





01



ALIENTA A/E	X1	X2
800X800	790	790
900X900	890	890
800X900	790	890
800X1000	790	990



02



[01] x2











[02] x1




[11] x6 (ST4x35)



[15] x1




03




[06] x2 [02] x1

[10] x4 (ST3.5x8)

[15] x1




04




[06] x2


[05] x2








05







[10] x4 (ST3.5x8)






06



07



08



09

